MANUAL/ GUIDE

Category: Registers

Type: Register Shroud / New Design

Issue: How to Install & Remove Prior Design





Removal of Old Register:

Step 1:Old version of register & housing



Step 2:Remove tamper seals with screwdriver or punch.



Step 3: Unscrew Mounting Screws



Step 4:Pull Cover Assembly Straight Up



Step 5:
Remove register shroud by opening gap and pulling off of body.



Step 6: *Meter with register and housing removed*





Installing New Shroud and Register:

Step 1:Starting position of twist on register shroud



Step 2:Twist clockwise until mechanical stop.

* Final position shown.



Step 3:Note locating indentations on register base each 90 degrees.



Step 4:Place register in shroud in preferred orientation.
Ensure indentation on register engage with tabs on shroud, preventing rotation.



Step 5:Place housing assembly onto the register approximately 15 degrees shy of final position.





Step 6:

Twist housing assembly 15 degrees clockwise. Use lid hinge (but not lid!) when twisting. The holes for the stopper snap pin should be a little past the midline when completed.



Step 8:

Use any available hard surface (in this case, screwdriver handle) to push stopper snap pin completely flush.



Step 7:

Insert stopper snap pin.

